

Plano Model Products - #14860
GP7/9 Intake Screens—Proto2000 Model

These stainless steel intake screens are designed for and intended to be used on Proto2000's GP7's and GP9's. Each group of screens are one piece assemblies with the screens attached to a frame that represents the prototype assembly

To add these screens to your model, you will need to remove the molded in plastic screens from the model. Accomplishing this depends on the tools you have available. One method would be to use a #60 drill bit and go around the edge of the screen drilling a series of holes. Make sure the holes are to the inside of the outer frame. The plastic screens make it real easy to keep the holes in line. Once you have all the holes drilled, if it didn't come out by it's self a straight edge blade around the edge should allow the old screens to come right out. A little file work around the opening to smooth it all out. The screen dividers can also be removed. The hardest part of this conversion will be removing the molded on frames around the screen openings. You will need a smooth and flat surface to apply these new grills to. Carefully carve and/or sand the frames off, being careful so you don't damage any surrounding details. The new screens will be centered over your cutouts and can be attached with a contact glue like Microscales Micro Bond, Barge glue or even RC plane canopy glue.

Thank you for using our product in your detailing project. Please visit your local hobby supplier for all of our photoetch details or visit us online at www.planomodelproducts.com

2701 W. 15th Street, #113, Plano, Texas 75075
www.planomodelproducts.com