

Plano Model Products - #14870
SD7/9 Intake Screens — Proto2000 Model

These stainless steel intake screens are designed for and intended to be used on Proto2000's SD7 and SD9 models. Each group of screens are one piece assemblies with the screens attached to a frame that represents the prototype assembly

To add these screens to your model, you will need to remove the molded in plastic screens from the model. Accomplishing this depends on the tools you have available. One method would be to use a #50 drill bit and go around the edge of the old plastic screen, drilling a series of holes. Make sure the holes are to the inside of the outer frame. The plastic screens make it easy to keep the holes in line. The plastic in this area is rather thick so it will take a little work to get these openings made. Once you have all the holes drilled, use a sharp straight edge blade to finish removing the old screens. A little file work around the edges of the openings to smooth it all out may be needed. The next step will be removing the molded on frames around the screen openings. You will need a smooth and flat surface to apply these new screens to. Carefully file and/or sand the frames off, being careful so you don't damage any surrounding details. The new screens will be centered over your cutouts and can be attached with a contact glue like Microscales Micro Bond, Barge glue or even RC plane canopy glue.

Thank you for using our product in your detailing project. Please visit your local hobby supplier for all of our photoetch details or visit us online at www.planomodelproducts.com

2701 W. 15th Street, #113, Plano, Texas 75075
www.planomodelproducts.com