

Plano Model Products - #14907 Proto2000 / WKW SD7 Step Set

These steps are designed to be used on the Proto2000 and Wm. K. Walthers SD7 model.

Carefully remove bottom plastic step from all four corners. Leave a small lip on the edges to mount the new brass step on.

Remove bottom steps from fret. Bend outer edge strip down at the score lines (score lines are inside of bends). Position step in correct corners so they rest on the small lips left from the old steps. Glue in place when satisfied with placement.

The remaining steps glue to the surface of the top two steps. Remove steps from fret. The front lip will bend down 90 degrees. There are small cuts to assist where the bends are to be made. Glue new steps to top surface of correct plastic steps.

Touch up paint as needed.

Thank you for using our product to detail your SD7.

*2701 W. 15th Street, #113, Plano Texas 75075
www.planomodelproducts.com*