

Plano Model Products - #14909 Proto2000 / WKW SD9 Step Set

These steps are designed to be used on the Proto2000 and Wm. K. Walthers SD9 model.

Carefully remove bottom and center plastic steps from all four corners. Leave a small lip on the edges to mount the new brass steps on. The bottom step kick plate can also be removed as a new one is attached to new bottom step.

Remove bottom and center steps from fret. Bend outer edge strip down at the score lines (score lines are inside of bends). The kick plate on the bottom steps bend up 90 degrees, against score line, in opposite direction of front lip. Position step in correct corners so they rest on the small lips left from the old steps. Glue in place when satisfied with placement.

The top steps glue to the surface of the top plastic steps. Remove steps from fret. The front lip will bend down 90 degrees. There are small cuts to assist where the bends are to be made. Glue new steps to top surface of correct plastic steps.

Touch up paint as needed.

Thank you for using our product to detail your SD9.

*2701 W. 15th Street, #113, Plano Texas 75075
www.planomodelproducts.com*