

**Plano Model Products - #14808
GP30 Non-dynamic Brake Hatch Plate**

These instructions are written with the assumption your model is an unassembled model. If there is a dynamic brake fan or one of the Proto2000 disks in place, you may want to remove it. These parts will need a clean, flat surface to mount to.

Glue the brass dynamic brake hatch over the opening of the dynamic brake. The holes in the plate should be offset toward the front of the unit.

Place the round hatch plate on the dynamic plate hatch and line up the holes. Insert a NBW into each hole. Add a dab of CA to the edge of the round plate to bond the two plates together. Carefully add a dab of CA to each NBW from the inside of the shell.

Choose one of the supplied lift rings and remove it from the fret, keeping the two halves joined together. To form the ring, carefully bend the two halves together at the half etch line, which is the outside of the bend. Carefully insert the folded liftring in hole in center of plate and CA in place.

This completes this portion of your detailing project. Please see your local hobby dealer for our full line of details. Or, visit us online

**2701 W. 15th Street, #113, Plano, TX 75075
www.planomodelproducts.com**